

# XMM-Newton data reduction

- XMM-Newton satellite , PN instrument
- from raw data to clean event file

# Software

- **FTOOLS** software for data analysis in **FITS format** (Flexible Image Transport System)
- test by typing “fhhelp ftools”
- **SAS** (Scientific analysis software) link: FTOOLS wrapper, tuned for XMM-Newton
- **IDL** (Interactive data language) link
- test by typing “idl”, help by typing “?”
- **ds9** and **fv** for FITS image visualisation

# SAS setup

- copy `/data/jnevalai/XMM/sas_setup.script` into your home directory
- edit the keyword **XMM\_DATA\_PATH** to point to your `/wrk/yourname/XMM` ( which will be referred as `/your_data_path`)
- execute “source `sas_setup.script`” to activate paths to SAS software
- write into `.cshrc` (so it will be executed when opening a new terminal)
- SAS starts by typing “sas”, test by typing “sashelp”
- must have FTOOLS active before running “sas”

# Script installation

- copy /data/jnevalai/XMM/install.script into your home directory
- execute “source install.script” (only once, the first time you install the scripts)
- the above command creates subdirectories “pipe”, “data” , “scripts” and “IDL” under */your\_data\_path*
- and copies programs into “IDL” and “scripts”, check this

# Obtaining data

- Go to XMM-Newton data archive <http://xmm.esac.esa.int/xsa/index.shtml>
- login/register
- Query with name “A1795” or “A3112”
- retrieve ODF
- copy the tar file to */your\_data\_path/pipe/data*

# Processing the raw data

- go to */your\_data\_path/pipe/data*
- copy there a file */your\_data\_path/pipe/scripts/do\_chain*
- edit the parameters
  - 3. parameter is your tar file
  - 4. parameter is the object name (  $\equiv$  *objname* )
  - 5. parameter is the observation ID (  $\equiv$  *obsid* )
  - 6. parameter is the observation date
  - 7. parameter is the instrument ID, use “P” for PN
- execute “source do\_chain” (after starting SAS and FTOOLS)
- program creates event files PN.FITS.gz and PNOOT.FITs.gz in  
*/your\_data\_path/pipe/data/objname/obsid/PN*